MA1811-EA

Quick Reference Manual 5582 CASIO

Congratulations upon your selection of this CASIO watch.

 $\mathsf{Bluetooth}^{\texttt{@}}$ is a registered trademark or trademark of Bluetooth SIG, Inc. of the United States.

Your watch has a Mobile Link function that allows it to communicate with a Bluetooth[®] mobile phone and adjust its time settings to match those of the mobile phone

- This product complies with or has received approval under radio laws in various countries and geographic areas. Use of this product in an area where it does not conform to or where it has not been approved under applicable radio laws may be punishable under local laws. For details, visit https://world.casio.com/ce/BLE/.

 Use of this product inside of an aircraft is restricted by the aviation laws of each
- country. Be sure to obey instructions provided by flight personnel concerning use of devices such as this product.

Visit the website below for the operation manual (Operation Guide) of this watch. https://world.casio.com/manual/wat/



Using the Watch

Charging

Remove the watch from your wrist and place it in a brightly lit area.


- The watch may become hot when exposed to light for charging. Take care to avoid
- · Avoid charging in locations where it is very hot.

- Leaving the watch in a dark location for about one hour between the hours of 10 p.m. and 6 a.m. will cause the second hand to stop at 12 o'clock.
- Leaving the watch in a dark location for about one week will cause all hands to stop.

Battery Alerts

- Low Battery
- Second hand jumps every two seconds (Low Battery Alert).
- Dead Battery
 All hands stopped

General Guide




- 1. Graphic area
- 2. Summer time display indicator
- 3. Phone connection standby
- 4. Phone connected*
- 5. Battery level
- 6, p.m. indicator (No indication for a.m.)
- 7. Hourly time signal enabled
- 8. Alarm enabled
- 9. Auto Light enabled
- 10. Recall Mode indicator
- 11. Hands shifted 12. Speed display indicator
- 13. Timer Mode indicator
- 14 Alarm Mode indicator
- 15. World Time Mode indicator
- * Hold down © for about 1.5 seconds to establish a Bluetooth connection with a phone.

Selecting a Mode


Each press of (1) cycles between modes as shown below.

• Hold down (2) for at least two seconds to enter the Timekeeping Mode.



Setting the Time

- 1. In the Timekeeping Mode, hold down (A). Release the button when the city
 - In a suppears.
 [SET] will flash and then the city name will appear.



2. Press (D) twice display the seconds



- 3. Press (E) to reset the seconds count to 00.
- 30 to 59 seconds: Adds 1 to minutes.
- 4. Press (1) to move the flashing to the hour setting.
- 5. Use (E) and (B) to change the setting.
- Press (1) to move the flashing to the minute setting.
- 7. Use (E) and (B) to change the setting.
- 8. Press (1) to move the flashing to the vear setting.
- 9. Use (E) and (B) to change the setting.
- Press (1) to move the flashing to the month setting.
- 11. Use (E) and (B) to change the setting.
- 12. Press (1) to move the flashing to the day setting.
- 13. Use (E) and (B) to change the setting.
- 14. Press (A) to exit the setting screen.

Specifications

Accuracy at Normal ±15 seconds per month average when time adjustment by

communication with a phone is not possible Analog Timekeeping: Hour, minute (moves every 10 seconds), second

Digital Timekeeping:

Hour, minute, second, month, day, day of the week, a.m./p.m. (P)/24-hour timekeeping, Full Auto Calendar (2000 to 2099), Summer Time

Measurement unit: 1/1000 seconds (first hour); 1/10 seconds (after first hour) Measurement range: 23 hours, 59 minutes, 59.9 seconds Measurement functions: Normal elapsed time; cumulative time; lap times; 200-record data memory

Measuring unit: 1/10 seconds Countdown range: 24 hours Setting unit: 1 second 10-second beeper at countdown end Timer:

Current time in 39 cities (39 time zones) plus UTC time: World Time:

summer time; Home City/World Time swapping

Alarms:

Selectable alarm type: DAILY, 1TIME, SCHEDULE DAILY, 1TIME
Setting units: Hour, minute

Setting units: Year, month, day, hour, minute Alarm tone duration: 10 seconds Hourly time signal: Beep every hour on the hour

Mobile Link:

Auto time correction
Time setting adjusted automatically at preset time.
One-touch time correction
Manual connection and time adjustment

Phone finder

Watch operation sounds the alert sound of the mobile phone.

Watch operation sounds the alert sound of the mobile pro-World Time Current time for approximately 300 cities selected for the watch Home Time/World Time swapping

Home Time/World Time swapping
Stopwatch data transfer
200 lap time records (date and time, lap time, lap number)
Auto summer time switching
Automatic switching between standard time and summer time
Timer setting
Hand position correction
Data Communication Specifications
Bluetooth®
Enguerous band: 2400 MHz to 2480 MHz

Frequency band: 2400 MHz to 2480 MHz

Maximum transmission: 0 dBm (1 mW)

Communication range: 2 meters max.

(depends on environment)

High-brightness DOUBLE LED light; illumination duration setting; Auto Light Switch (Full Auto Light operates only in the dark); operation tone on/off; Hand Shift; Battery level indicator, Power saving

Power Supply: Solar panel and 1 rechargeable battery

Approximate Battery Life:

Other:

6 months

- Auto time correction: 4 times/day
- Alarm: Once (10 seconds)/day
 Illumination: Once (1.5 seconds)/day
- Power saving: 6 hours/day

Specifications are subject to change without notice